

User Guide for the CONNEXION™ Series Fire Alarm Control Panels

To Silence the Internal FAULT SOUNDER

Press the MUTE BUZZER button.



To Silence the Alarm Sounders

Press the SILENCE/RESOUND ALARMS button.



Using the numeric buttons enter the access code 1234 and then press the OK circular button



Next press the SILENCE/RESOUND ALARMS button.



Do not press the RESET button until you have identified the cause of the alarm signal and you confirm it is clear.

To Reset the System

Unless you have already done so press the RESET button



Use the numeric buttons to enter the access code 1234 and then press the OK circular button



Then press the RESET button



If the RESET button is pressed while the alarm condition still exists this will cause the Sounders to resound.

